

# Folding the Smoke Blocker

Folding the Slate River Corp

Smoke Blocker



Lay out flat with hook loop strips up



Fold in half with window on top

Fold from top to bottom at top  
of window seam (avoid creasing  
window).







Fold bottom over creating crease at top

Fold again at leather bottom







Fold in half





Properly folded for stowage